

Addendum to AcroPro Manual

Line Stow Procedures for AcroPro Para-Cushions with line stow bars located in bottom of container.

Replace section 6.3 of the original manual dated Jan 2014 with the following steps:

6.3 Riser and Line Stows

6.3.1

Insert the T-bars up through the three grommets located in the bottom of the container.



6.3.2

Hold both line groups together just above the left riser group. Make sure that all lines are even between canopy and left riser group. As a group make a stow in the bottom left outboard retainer band.



Note:

This bight should contain all the lines. There will be excess in the right line group between the riser links and this first line stow.

6.3.3

Close the riser covers over the left and right risers by mating the hook and loop Velcro. Make sure to keep lines out of the Velcro. Right ling group will be 14-16" longer than the left line group.

**6.3.4**

Remove all the slack from the right line group, by slightly pulling the lines. Fold the lines over and make a stow of this right line group in the inside most retainer band located in the upper right corner of the container.

STOP: Rigger check.

1. Riser covers closed.
2. Complete line stow in lower left corner of container.
3. Excess line stowed in upper right corner of container.

**6.3.5**

Take all the suspension lines in a group and make a stow in the outside most retainer band located in the upper left corner of the container.



6.3.6

Next make a stow of all suspension lines in the center retainer band in the lower left corner of the container. Continue stowing lines in this manner until you have two stows in the upper retainer bands and three stows in the lower retainer bands.

**6.3.7**

Route the lines between the bottom and middle grommets located in the container, then to the inside most retainer band located in the lower right corner of the container.

**Note!**

Ensure that lines run between middle and bottom grommet. Routing lines below the bottom grommet could cause a malfunction.

6.3.8

Stow the suspension lines on the right side from the inside to the outside. The last stow should be in the outside most retainer band located in the upper right corner of the container. Leave approximately 6-8" of line between the last stow and the canopy.

**STOP: Rigger check.**

1. All lines stowed.
2. All lines are clear of all grommets.